



# Power Steering Flush

**SUPER CONCENTRATED FORMULA**  
For use with or without a flush machine



## DESCRIPTION:

Power steering systems are generally only noticed when something has gone wrong. This system is one of the simplest to maintain and is also the most noticed complaint from a customer with their vehicle.

A power steering system is generally subject to harsh temperatures leading to fluid deterioration over time. Through constant use and high operating pressures, other types of wear materials are also generated that degrade the system. The result of this pressure and heat is fluid breakdown, contamination, loss of lubricating properties, and varnish deposits. When power steering fluid circulates throughout the system of pump and gear, it picks up wear material as well as contamination from the breakdown of aging hoses and seals. Periodic maintenance of this intricate and precise system is necessary!

Flushing this system with LUBEGARD® Power Steering Flush & recharging it with new fluid and adding LUBEGARD Power Steering Fluid Protectant (P/N 20404) is the best assurance you can have for extended optimum power steering performance by allowing the fluid to run through the system effortlessly, providing the driver responsive and safe control. Even though most manufacturer's don't provide a maintenance schedule for this important gear, it should be flushed and refilled any time work is done on the rack, a hose is replaced, or if you are having steering squawk or other operating problems.

## BENEFITS:

- Safely removes deposits and impurities
- Conditions and revitalizes seals and components
- Prepares system for new fluid
- Deters hard-steering and squawks on cold starts
- Deters internal power steering fluid leakage from developing



## DIRECTIONS:

STEP 1. Directions: With Flush Machine – Follow Manufacturer's Directions. Without Flush Machine – Open the reservoir & add one bottle of LUBEGARD® power steering FLUSH, do not overfill. With car in park and brake on, start engine. Turn steering wheel at least 4 times all the way left and right. Shut off engine and remove old fluid

STEP 2. To refill; Open the power steering reservoir. Add 4 fl oz (118 mL) LUBEGARD Power Steering Fluid Protectant and top off with appropriate power steering fluid to proper level. Caution: Do not overfill. Do not use in systems that use brake fluid.



Also available in a Flush and Protect Performance Pack

P/N 98404

## TYPICAL PROPERTIES:

Viscosity @ 40°C.....30-35 cSt  
 Viscosity @ 100°C .....5-8 cSt  
 Flash Point, COC ..... >400°F  
 Pour Point ..... 10°F

## AVAILABILITY:

Stock No.	Unit Size	Case Weight/QNTY
95040	4 oz.	3.55lbs./(12/case)

